


STM32F4xx Introduction

IE 5995: IoT and Edge AI Programming
Dr. Yanchao Liu
Industrial & Systems Engineering
Wayne State University



Agenda

- Learn the STM32F4xx NUCLEO board layout and features
- Install the development toolchain
- Create STM32 projects, configure, build, and download
- Understand the code organization
- Use GPIO for digital input and output
- Learn basic debugging functions
- Use Interrupts
- Use Timers and Timer-triggered Interrupts
- Use UART to transmit and receive data (poll, interrupt and DMA)
- Use ADC, PWM, DAC, DMA


NUCLEO board codification

NUCLEO-XXYYZT NUCLEO-XXYYZT-P	Description	Example: NUCLEO-L452RE
XX	MCU series in STM32 Arm Cortex MCUs	STM32L4 Series
YY	MCU product line in the series	STM32L452
Z	STM32 package pin count - C for 48 pins - R for 64 pins	64 pins
T	STM32 Flash memory size: 6 for 32 Kbytes 8 for 64 Kbytes - B for 128 Kbytes - C for 256 Kbytes - E for 512 Kbytes - G for 1 Mbyte - Z for 192 Kbytes	512 Kbytes
-P	STM32 has external SMPS function	No SMPS

STM32 Nucleo-64 boards

Common features

- STM32 microcontroller in LQFP64 or LQFP48 package
- 1 user LED shared with ARDUINO®
- 1 user and 1 reset push-buttons
- 32.768 kHz crystal oscillator
- Board connectors:
 - ARDUINO® Uno V3 expansion connector
 - ST morpho extension pin headers for full access to all STM32 I/Os
- Flexible power-supply options: ST-LINK USB VBUS or external sources
- On-board ST-LINK debugger/programmer with USB re-enumeration
- Capability: mass storage, Virtual COM port, and debug port
- Comprehensive free software libraries and examples available with the
- STM32Cube MCU Package
- Support of a wide choice of Integrated Development Environments (IDEs)
 - Including IAR Embedded Workbench®, MDK-ARM, and STM32CubeIDE




STM32 Nucleo product line

Development toolchains


- IAR Systems® - IAR Embedded Workbench®
- Keil® - MDK-ARM
- STMicroelectronics - STM32CubeIDE

The first two are Windows only. We will use STM32CubeIDE.




STM32F446RE NUCLEO

- Find these elements on the board
 - B1 (User button), B2 (Reset button)
 - LD1 (three-color led), LD2 (green led), LD3 (red led)



Understand the Pin labels



- PA10 means
 - GPIO Port A (GPIOA)
 - GPIO_PIN_10
- So, to write HIGH to PA10, call this function:
 - `HAL_GPIO_WritePin(GPIOA, GPIO_PIN_10, GPIO_PIN_SET);`
- More on the functions later

Arduino connectors on NUCLEO-F446RE

CN5, CN6, CN8, and CN9 are female connectors compatible with ARDUINO® standard. Most shields designed for ARDUINO® can fit the STM32 Nucleo boards.

Connector	Pin	Pin name	STM32 pin	Function
Left connectors				
CN6 power	1	NC	-	-
	2	IOREF	-	3.3V Ref
	3	RESET	NRST	RESET
	4	+3.3V	-	3.3V input/output
	5	+5V	-	5V output
	6	GND	-	ground
	7	GND	-	ground
	8	VIN	-	Power input
CN8 analog	1	A0	PA0	ADC123_IN0
	2	A1	PA1	ADC123_IN1
	3	A2	PA4	ADC12_IN4
	4	A3	PB0	ADC12_IN8
	5	A4	PC1 or PB9 ⁽¹⁾	ADC123_IN11 (PC1) or I2C1_SDA (PB9)
	6	A5	PC0 or PB8(1)	ADC123_IN10 (PC0) or I2C1_SCL (PB8)
Right connectors				
CN5 digital	10	D15	PB8	I2C1_SCL
	9	D14	PB9	I2C1_SDA

Connector	Pin	Pin name	STM32 pin	Function
CN5 digital	8	AREF	-	AVDD
	7	GND	-	ground
	6	D13	PA5	SPI1_SCK
	5	D12	PA6	SPI1_MISO
	4	D11	PA7	TIM14_CH1 SPI1_MOSI
	3	D10	PB6	TIM4_CH1 SPI1_CS
	2	D9	PC7	TIM8_CH2
	1	D8	PA9	-
	8	D7	PA8	-
CN9 digital	7	D6	PB10	TIM2_CH3
	6	D5	PB4	TIM3_CH1
	5	D4	PB5	-
	4	D3	PB3	TIM2_CH2
	3	D2	PA10	-
	2	D1	PA2	USART2_TX
	1	D0	PA3	USART2_RX

ST morpho connector on NUCLEO-F446RE

CN7 odd pins		CN7 even pins		CN10 odd pins		CN10 even pins	
Pin	Name	Name	Pin	Pin	Name	Name	Pin
1	PC10	PC11	2	1	PC9	PC8	2
3	PC12	PD2	4	3	PB8	PC6	4
5	VDD	E5V	6	5	PB9	PC5	6
7	BOOT0 ⁽¹⁾	GND	8	7	AVDD	U5V ⁽²⁾	8
9	-	-	10	9	GND	-	10
11	-	IOREF	12	11	PA5	PA12	12
13	PA13 ⁽³⁾	RESET	14	13	PA6	PA11	14
15	PA14 ⁽³⁾	+3.3V	16	15	PA7	PB12	16
17	PA15	+5V	18	17	PB6	-	18
19	GND	GND	20	19	PC7	GND	20
21	PB7	GND	22	21	PA9	PB2	22
23	PC13	VIN	24	23	PA8	PB1	24
25	PC14	-	26	25	PB10	PB15	26
27	PC15	PA0	28	27	PB4	PB14	28
29	PH0	PA1	30	29	PB5	PB13	30
31	PH1	PA4	32	31	PB3	AGND	32
33	VBAT	PB0	34	33	PA10	PC4	34
35	PC2	PC1 or PB9 ⁽⁴⁾	36	35	PA2	-	36
37	PC3	PC0 or PB8 ⁽⁴⁾	38	37	PA3	-	38

1. The default state of BOOT0 is LOW. It can be set to HIGH when a jumper is on pin5-7 of CN7. Two unused jumpers are available on CN11 and CN12 (bottom side of the board).
2. U5V is 5 V power from ST-LINK/V2-1 USB connector and it rises before +5V.
3. PA13 and PA14 share with SWD signals connected to ST-LINK/V2-1, it is not recommended to use them as IO pins if the ST-LINK part is not cut.

Spare jumpers



LEDs on the NUCLEO board

The tricolor LED (green, orange, red) LD1 (COM) provides information about ST-LINK communication status. LD1 default color is red. LD1 turns to green to indicate that communication is in progress between the PC and the ST-LINK/V2-1, with the following setup:

- Slow blinking Red/Off: at power-on before USB initialization
- Fast blinking Red/Off: after the first correct communication between the PC and ST-LINK/V2-1 (enumeration)
- Red LED On: when the initialization between the PC and ST-LINK/V2-1 is complete
- Green LED On: after a successful target communication initialization
- Blinking Red/Green: during communication with the target
- Green On: communication finished and successful
- Orange On: Communication failure

User LD2: the green LED is a user LED connected to ARDUINO[®] signal D13 corresponding to STM32 I/O PA5 (pin 21) or PB13 (pin 34) depending on the STM32 target. Refer to [Table 11](#) to [Table 23](#) when:


- the I/O is HIGH value, the LED is on
- the I/O is LOW, the LED is off

LD3 PWR: the red LED indicates that the STM32 part is powered and +5V power is available.

Toolchain installation

- We need to install the following software on the PC
 - STM32CubeProgrammer
 - <https://www.st.com/en/development-tools/stm32cubeprog.html>
 - STM32CubeIDE
 - <https://www.st.com/en/development-tools/stm32cubeide.html>


STM32CubeIDE



- Click "Start new STM32 project"
- Some additional downloads will happen

Create a project using STM32CubeIDE

- Click the “Board Selector” tab
- Select the board NUCLEO-F446RE from the dropdown menu
- Before clicking “Next”, download the manuals from Docs & Resources
 - The docs will be saved to {HOME}/STM32Cube/Repository
 - Take a quick scan of the docs to see what info is in there, for future reference
- Click “Next”




Some important points from the documents

- The STM32 Nucleo board and its shield can **consume a maximum of 300 mA current**, not more.
- The USART2 interface available on PA2 and PA3 of the STM32 microcontroller can be connected to ST-LINK MCU, ST morpho connector, or to ARDUINO® connector. The choice can be changed by setting the related solder bridges. By default, the USART2 communication between the target STM32 and ST-LINK MCU is enabled, in order to support virtual COM port for Mbed™ (SB13 and SB14 ON, SB62 and SB63 OFF).
- If the communication between the target STM32 PA2 (D1) or PA3 (D0) and shield or extension board is required, SB62 and SB63 must be ON, while SB13 and SB14 must be OFF.


HelloWorld project




- Type in the project name, e.g., HelloWorld
- Click “Finish”
- Click “Yes” to initialize peripherals with their default mode.
- Click “Yes” to open the Device Configuration Tool perspective.
 - Before the perspective is loaded, some additional downloads (~700MB) will occur



Configure and generate code

- Feel free to navigate the four tabs:
 - Pinout & Configuration
 - Clock Configuration
 - Project Manager
 - Tools
- Next slide show the four tabs
- Don't change anything
- In menu, click Project -> Generate Code
- Click "Yes" to open the code perspective



Code perspective

- Always write user code within the


```
/* USER CODE BEGIN .. */
```

```
...
```

```
/* USER CODE END .. */
```


blocks.

- User code written outside such blocks will be wiped next time “Generate Code” is run after some configuration change.



Build the project

- For now, don't make any change to the code
- In the menu, click "Project -> Build Project"
- The build should finish quickly with no error or warning.
- In File Explore, go to the project folder
 - E.g., C:\Users\gn0061\STM32CubeIDE\workspace_1.8.0\HelloWorld\
- **HelloWorld.bin** is the file to send to the board, through the STM32CubeProgrammer



Download the program to the board


- Open the Programmer
- Connect to board (ST-LINK)
- Go to “Erasing & Programming”
- Browse and select the HelloWorld.bin file.
- Click “Start Programming”

Note: whatever content that was previously on the board will be erased.

After the programming, the board is reset and the new program will run automatically. In this case, the program does nothing.

We've successfully created our first program on the board.

Whenever the board is powered, the program will run automatically.



main.c

- We can see that B1 (the user button) and LD2 (the green led) are enabled, and the LD2 is reset

```
187  * @retval None
188  */
189 static void MX_GPIO_Init(void)
190 {
191     GPIO_InitTypeDef GPIO_InitStruct = {0};
192
193     /* GPIO Ports Clock Enable */
194     __HAL_RCC_GPIOC_CLK_ENABLE();
195     __HAL_RCC_GPIOH_CLK_ENABLE();
196     __HAL_RCC_GPIOA_CLK_ENABLE();
197     __HAL_RCC_GPIOB_CLK_ENABLE();
198
199     /*Configure GPIO pin Output Level */
200     HAL_GPIO_WritePin(LD2_GPIO_Port, LD2_Pin, GPIO_PIN_RESET);
201
202     /*Configure GPIO pin : B1_Pin */
203     GPIO_InitStruct.Pin = B1_Pin;
204     GPIO_InitStruct.Mode = GPIO_MODE_IT_FALLING;
205     GPIO_InitStruct.Pull = GPIO_NOPULL;
206     HAL_GPIO_Init(B1_GPIO_Port, &GPIO_InitStruct);
207
208     /*Configure GPIO pin : LD2_Pin */
209     GPIO_InitStruct.Pin = LD2_Pin;
210     GPIO_InitStruct.Mode = GPIO_MODE_OUTPUT_PP;
211     GPIO_InitStruct.Pull = GPIO_NOPULL;
212     GPIO_InitStruct.Speed = GPIO_SPEED_FREQ_LOW;
213     HAL_GPIO_Init(LD2_GPIO_Port, &GPIO_InitStruct);
214 }
215
216 /* USER CODE BEGIN 4 */
217
218 /* USER CODE END 4 */
219
220 /**
221  *
222  */
```

main.h

- uart2 : UART_HandleTypeDef
- SystemClock_Config(void) : void
- MX_GPIO_Init(void) : void
- MX_USART2_UART_Init(void) : void
- main(void) : int
- SystemClock_Config(void) : void
- MX_USART2_UART_Init(void) : void
- MX_GPIO_Init(void) : void
- Error_Handler(void) : void
- assert_failed(uint8_t*, uint32_t) : void

Note how the **GPIO_InitStruct** is configured. We will see details of this later.


GPIO_PIN_RESET means 0
GPIO_PIN_SET means 1

main.c

- Check out the main function
- Add some functionality
 - Add the following two lines in the while loop

```
/* Infinite loop */
/* USER CODE BEGIN WHILE */
while (1)
{
    /* USER CODE END WHILE */

    /* USER CODE BEGIN 3 */
    HAL_GPIO_TogglePin(LD2_GPIO_Port, LD2_Pin);
    HAL_Delay(500);
}
/* USER CODE END 3 */
```



The names such as “LD2_GPIO_Port” and “LD2_Pin” are defined in main.h file (which was generated automatically)

```
66 int main(void)
67 {
68     /* USER CODE BEGIN 1 */
69
70     /* USER CODE END 1 */
71
72     /* MCU Configuration-----*/
73
74     /* Reset of all peripherals, Initializes the Flash interface and the Systick. */
75     HAL_Init();
76
77     /* USER CODE BEGIN Init */
78
79     /* USER CODE END Init */
80
81     /* Configure the system clock */
82     SystemClock_Config();
83
84     /* USER CODE BEGIN SysInit */
85
86     /* USER CODE END SysInit */
87
88     /* Initialize all configured peripherals */
89     MX_GPIO_Init();
90     MX_USART2_UART_Init();
91     /* USER CODE BEGIN 2 */
92
93     /* USER CODE END 2 */
94
95     /* Infinite loop */
96     /* USER CODE BEGIN WHILE */
97     while (1)
98     {
99         /* USER CODE END WHILE */
100
101         /* USER CODE BEGIN 3 */
102     }
103     /* USER CODE END 3 */
104 }
105
```

Save, Build Project, then download the HelloWorld.bin file to the board. The green led should blink (toggle on/off every 500 ms). If the program does not run automatically, press the Reset button on the board.

Definitions


```
/* Private defines -----  
#define B1_Pin GPIO_PIN_13  
#define B1_GPIO_Port GPIOC  
#define USART_TX_Pin GPIO_PIN_2  
#define USART_TX_GPIO_Port GPIOA  
#define USART_RX_Pin GPIO_PIN_3  
#define USART_RX_GPIO_Port GPIOA  
#define LD2_Pin GPIO_PIN_5  
#define LD2_GPIO_Port GPIOA  
#define TMS_Pin GPIO_PIN_13  
#define TMS_GPIO_Port GPIOA  
#define TCK_Pin GPIO_PIN_14  
#define TCK_GPIO_Port GPIOA  
#define SWO_Pin GPIO_PIN_3  
#define SWO_GPIO_Port GPIOB  
/* USER CODE BEGIN Private defines */  
  
/* USER CODE END Private defines */
```

- Some shorthand names are defined in main.h
- For example:
 - LD2_Pin is alias for GPIO_PIN_5
 - But where is GPIO_PIN_5 define?
 - It is defined in the stm34f4xx_hal_gpio.h

HAL_GPIO_TogglePin(LD2_GPIO_Port, LD2_Pin);

- Where is the HAL_ function defined?
- What other GPIO functions are available?

Check out the Drivers/STM32F4xx_HAL_Driver folder in the source code



Some other GPIO functions

```
/* IO operation functions *****/
GPIO_PinState HAL_GPIO_ReadPin(GPIO_TypeDef* GPIOx, uint16_t GPIO_Pin);
void HAL_GPIO_WritePin(GPIO_TypeDef* GPIOx, uint16_t GPIO_Pin, GPIO_PinState PinState);
void HAL_GPIO_TogglePin(GPIO_TypeDef* GPIOx, uint16_t GPIO_Pin);
HAL_StatusTypeDef HAL_GPIO_LockPin(GPIO_TypeDef* GPIOx, uint16_t GPIO_Pin);
void HAL_GPIO_EXTI_IRQHandler(uint16_t GPIO_Pin);
void HAL_GPIO_EXTI_Callback(uint16_t GPIO_Pin);
```

```
typedef enum
{
    GPIO_PIN_RESET = 0,
    GPIO_PIN_SET
}GPIO_PinState;
```

This means
GPIO_PIN_RESET is alias for 0 (Low)
GPIO_PIN_SET is alias for 1 (High)

```
/** @defgroup GPIO_pins_define GPIO pins define
 * @{
 */
#define GPIO_PIN_0 ((uint16_t)0x0001) /* Pin 0 selected */
#define GPIO_PIN_1 ((uint16_t)0x0002) /* Pin 1 selected */
#define GPIO_PIN_2 ((uint16_t)0x0004) /* Pin 2 selected */
#define GPIO_PIN_3 ((uint16_t)0x0008) /* Pin 3 selected */
#define GPIO_PIN_4 ((uint16_t)0x0010) /* Pin 4 selected */
#define GPIO_PIN_5 ((uint16_t)0x0020) /* Pin 5 selected */
#define GPIO_PIN_6 ((uint16_t)0x0040) /* Pin 6 selected */
#define GPIO_PIN_7 ((uint16_t)0x0080) /* Pin 7 selected */
#define GPIO_PIN_8 ((uint16_t)0x0100) /* Pin 8 selected */
#define GPIO_PIN_9 ((uint16_t)0x0200) /* Pin 9 selected */
#define GPIO_PIN_10 ((uint16_t)0x0400) /* Pin 10 selected */
#define GPIO_PIN_11 ((uint16_t)0x0800) /* Pin 11 selected */
#define GPIO_PIN_12 ((uint16_t)0x1000) /* Pin 12 selected */
#define GPIO_PIN_13 ((uint16_t)0x2000) /* Pin 13 selected */
#define GPIO_PIN_14 ((uint16_t)0x4000) /* Pin 14 selected */
#define GPIO_PIN_15 ((uint16_t)0x8000) /* Pin 15 selected */
#define GPIO_PIN_All ((uint16_t)0xFFFF) /* All pins selected */
```

So, another way of blinking the green led is:

```
/* Infinite loop */
/* USER CODE BEGIN WHILE */
while (1)
{
    /* USER CODE END WHILE */
    HAL_GPIO_WritePin(LD2_GPIO_Port, LD2_Pin, GPIO_PIN_SET);
    HAL_Delay(500);
    HAL_GPIO_WritePin(LD2_GPIO_Port, LD2_Pin, GPIO_PIN_RESET);
    HAL_Delay(500);
    /* USER CODE BEGIN 3 */
}
/* USER CODE END 3 */
}
```

Exercise 1: Modify the content in the while (1) loop to realize this:

- When the blue button (B1_Pin) is pressed (PinState is 0), the green led is on; otherwise, the green led is off.


Hint: Use the HAL_GPIO_ReadPin function.

GPIO_InitStruct.Mode, .Pull, .Speed defs

```
119 #define GPIO_MODE_INPUT          0x00000000U  /*!< Input Floating Mode */
120 #define GPIO_MODE_OUTPUT_PP      0x00000001U  /*!< Output Push Pull Mode */
121 #define GPIO_MODE_OUTPUT_OD      0x00000011U  /*!< Output Open Drain Mode */
122 #define GPIO_MODE_AF_PP          0x0000002U   /*!< Alternate Function Push Pull Mode */
123 #define GPIO_MODE_AF_OD          0x00000012U   /*!< Alternate Function Open Drain Mode */
124
125 #define GPIO_MODE_ANALOG          0x00000003U  /*!< Analog Mode */
126
127 #define GPIO_MODE_IT_RISING       0x10110000U  /*!< External Interrupt Mode with Rising edge trigger detection */
128 #define GPIO_MODE_IT_FALLING     0x10210000U  /*!< External Interrupt Mode with Falling edge trigger detection */
129 #define GPIO_MODE_IT_RISING_FALLING 0x10310000U /*!< External Interrupt Mode with Rising/Falling edge trigger detection */
130
131 #define GPIO_MODE_EVT_RISING      0x10120000U  /*!< External Event Mode with Rising edge trigger detection */
132 #define GPIO_MODE_EVT_FALLING     0x10220000U  /*!< External Event Mode with Falling edge trigger detection */
133 #define GPIO_MODE_EVT_RISING_FALLING 0x10320000U /*!< External Event Mode with Rising/Falling edge trigger detection */
134 /**
135  * @}
136  */
137
138 /** @defgroup GPIO_speed_define GPIO speed define
139  * @brief GPIO Output Maximum frequency
140  * @{
141  */
142 #define GPIO_SPEED_FREQ_LOW       0x00000000U  /*!< IO works at 2 MHz, please refer to the product datasheet */
143 #define GPIO_SPEED_FREQ_MEDIUM    0x00000001U  /*!< range 12,5 MHz to 50 MHz, please refer to the product datasheet */
144 #define GPIO_SPEED_FREQ_HIGH      0x00000002U  /*!< range 25 MHz to 100 MHz, please refer to the product datasheet */
145 #define GPIO_SPEED_FREQ_VERY_HIGH 0x00000003U  /*!< range 50 MHz to 200 MHz, please refer to the product datasheet */
146 /**
147  * @}
148  */
149
150 /** @defgroup GPIO_pull_define GPIO pull define
151  * @brief GPIO Pull-Up or Pull-Down Activation
152  * @{
153  */
154 #define GPIO_NOPULL                0x00000000U  /*!< No Pull-up or Pull-down activation */
155 #define GPIO_PULLUP                 0x00000001U  /*!< Pull-up activation */
156 #define GPIO_PULLDOWN               0x00000002U  /*!< Pull-down activation */
```

Use other GPIO pins (e.g., PA_10)

- Double click HelloWorld.ioc in the Project Explore pane to open the Device Configuration perspective
- Change the role of PA10 to GPIO_Output in the Pinout & Configuration view (see pic)
- Click the save button , click “Yes” to the question “Do you want generate code?”, then click “Yes” to open the code perspective.



Regenerated MX_GPIO_Init code in main.c

```
static void MX_GPIO_Init(void)
{
    GPIO_InitTypeDef GPIO_InitStructure = {0};

    /* GPIO Ports Clock Enable */
    __HAL_RCC_GPIOC_CLK_ENABLE();
    __HAL_RCC_GPIOH_CLK_ENABLE();
    __HAL_RCC_GPIOA_CLK_ENABLE();
    __HAL_RCC_GPIOB_CLK_ENABLE();

    /*Configure GPIO pin Output Level */
    HAL_GPIO_WritePin(GPIOA, LD2_Pin|GPIO_PIN_10, GPIO_PIN_RESET);



    /*Configure GPIO pin : B1_Pin */
    GPIO_InitStructure.Pin = B1_Pin;
    GPIO_InitStructure.Mode = GPIO_MODE_IT_FALLING;
    GPIO_InitStructure.Pull = GPIO_NOPULL;
    HAL_GPIO_Init(B1_GPIO_Port, &GPIO_InitStructure);

    /*Configure GPIO pins : LD2_Pin PA10 */
    GPIO_InitStructure.Pin = LD2_Pin|GPIO_PIN_10;
    GPIO_InitStructure.Mode = GPIO_MODE_OUTPUT_PP;
    GPIO_InitStructure.Pull = GPIO_NOPULL;
    GPIO_InitStructure.Speed = GPIO_SPEED_FREQ_LOW;
    HAL_GPIO_Init(GPIOA, &GPIO_InitStructure);
}
```

- LD2_Pin | GPIO_PIN_10
- Both LD2_Pin (alias for GPIO_PIN_5) and GPIO_PIN_10 are enabled on GPIO Port A (GPIOA)

Hardware connection

- Let PA_10 (now configured as a digital output pin) to drive a led




Write user code

- If the blue button (B1_Pin, or equivalently GPIO_Pin_13) is pressed, then light up the led connected to PA_10; otherwise, turn off the led

```
/* Infinite loop */
/* USER CODE BEGIN WHILE */
while (1)
{
    /* USER CODE END WHILE */

    /* USER CODE BEGIN 3 */
    if(HAL_GPIO_ReadPin(B1_GPIO_Port, B1_Pin) == GPIO_PIN_RESET){
        HAL_GPIO_WritePin(GPIOA, GPIO_PIN_10, GPIO_PIN_SET);
    } else {
        HAL_GPIO_WritePin(GPIOA, GPIO_PIN_10, GPIO_PIN_RESET);
    }
}
/* USER CODE END 3 */
```



Exercises

1. Use the blue button to toggle the led connected to PA_10.
 - Toggle means: click -> turn on, click again -> turn off
2. Connect a tactile switch to PA_8, set PA_8 as digital input, and use the switch to toggle the led connected to PA_10


Tactile switch




Debug functions

```
55
56 /* Private user code ----- */
57 /* USER CODE BEGIN 0 */
58 int counter = 0;
59 /* USER CODE END 0 */
60
61 /**
62  * @brief The application entry point.
63  * @retval int
64  */
65 int main(void)
66 {
67     /* USER CODE BEGIN 1 */
68
69     /* USER CODE END 1 */
70
71     /* Infinite loop */
72     /* USER CODE BEGIN WHILE */
73     while (1)
74     {
75         /* USER CODE END WHILE */
76
77         /* USER CODE BEGIN 3 */
78         HAL_GPIO_TogglePin(LD2_GPIO_Port, LD2_Pin);
79         HAL_Delay(500);
80         counter++;
81         if(counter > 20){
82             counter = 0;
83         }
84     }
85     /* USER CODE END 3 */
86 }
```

- We will monitor a global variable
 - int counter = 0
- Increment the counter every 500 ms, and reset when hit 20
- We are going to monitor the value of this variable while the program is running
- Make sure Debug is “Serial Wire”
 - PA13 and PA14 will be used automatically







Debug Configuration

- Make sure the board is connected to the PC via USB
 - It should not be in active connection elsewhere, i.e., STM32CubeProgrammer
- Go to Run -> Debug Configuration
- Click the Debugger tab
- Check the box “ST-LINK S/N”, click Scan, and select the board ID
- Check “Enable” under SWV
- Set Core Clock (MHz) to 84.0
 - This value is read from the HCLK value from the Clock Configuration page
- “Enable live expressions” is checked
- Click Debug


The Debug perspective




- In the Live Expressions tab, add the variable name “counter” as a new expression
- Hit the play button (or F8), the program will run on board, and the counter value is displayed in the Live Expression view in real-time
- Hit the suspend button to pause the program
- Go to Window -> Show View -> SWV -> SWV Data Trace



- Click “Configure trace”
- Add “counter” to comparator 0
- Turn on “Start Trace” button





Use Interrupts

The screenshot shows the STM32CubeMX Pinout & Configuration window. The left sidebar lists various system components, with GPIO selected. The main area displays the 'GPIO Mode and Configuration' for PC13. The configuration table shows PC13 is configured as an external interrupt with falling edge trigger detection. The right sidebar shows the pinout view of the STM32F446RE LQFP64 package, with PC13 highlighted in blue.

Pinout & Configuration

Software Packs

Pinout

GPIO Mode and Configuration

Configuration

Group By Peripherals

GPIO Single Mapped Signals RCC SYS USART NVIC

Search Signals

Search (Ctrl+F)

Show only Modified Pins

Pin Name	Signal on Pin	GPIO output	GPIO mode	GPIO Pull-up	Maximum ou...	User Label	Modified
PA5	n/a	Low	Output Push...	No pull-up a...	Low	LD2 [Green ...	✓
PC13	n/a	n/a	External Inte...	No pull-up a...	n/a	B1 [Blue Pu...	✓

PC13 Configuration :

GPIO mode: External Interrupt Mode with Falling edge trigger detection

GPIO Pull-up/Pull-down: No pull-up and no pull-down

User Label: B1 [Blue PushButton]

Pinout view

System view

STM32F446RE LQFP64

PC13

B1 [Blue PushButton]

LD2 [Green Led]

- Configure PC13 (the blue button) as GPIO_EXTI13
- Set GPIO mode (Falling edge trigger)


Enable EXTI 15:10 interrupts in NVIC

The screenshot shows the STM32CubeMX Pinout & Configuration window. The 'NVIC Mode and Configuration' tab is active, displaying the 'NVIC Interrupt Table'. The 'EXTI line[15:10] interrupts' row is highlighted, and the 'Enabled' checkbox is checked. The 'Priority Group' is set to '0 bits f...'. The 'Pinout view' on the right shows the STM32F446RE LQFP64 package with various pins labeled, including PC13.

NVIC Interrupt Table	Enabled	Preemption Priority	Sub Priority
Non maskable interrupt	☒	0	0
Hard fault interrupt	☒	0	0
Memory management fault	☒	0	0
Pre-fetch fault, memory access fault	☒	0	0
Undefined instruction or illegal state	☒	0	0
System service call via SWI instruction	☒	0	0
Debug monitor	☒	0	0
Pendable request for system service	☒	0	0
Time base: System tick timer	☒	0	0
PVD interrupt through EXTI line 16	☐	0	0
Flash global interrupt	☐	0	0
RCC global interrupt	☐	0	0
USART2 global interrupt	☐	0	0
EXTI line[15:10] interrupts	☒	0	0
FPU global interrupt	☐	0	0

- PC13 is grouped together with many other pins into a common NVIC IRQ named EXTI15_10_IRQ.
- We have to enable it to use PC13 pin for interrupt.
- Disregard the priority setting, just use the default 0.
 - Smaller value means higher priority.

IRQ Handler invocation chain



```
194 .....  
195 /* STM32F4xx Peripheral Interrupt Handlers */  
196 /* Add here the Interrupt Handlers for the used peripherals. */  
197 /* For the available peripheral interrupt handler names, */  
198 /* please refer to the startup file (startup_stm32f4xx.s). */  
199 /**  
200  
201  * @brief This function handles EXTI line[15:10] interrupts.  
202  */  
203  
204 void EXTI15_10_IRQHandler(void)  
205 {  
206     /* USER CODE BEGIN EXTI15_10_IRQn 0 */  
207  
208     /* USER CODE END EXTI15_10_IRQn 0 */  
209     HAL_GPIO_EXTI_IRQHandler(B1_Pin);  
210     /* USER CODE BEGIN EXTI15_10_IRQn 1 */  
211  
212     /* USER CODE END EXTI15_10_IRQn 1 */  
213 }  
214  
215 /* USER CODE BEGIN 1 */  
216  
217 /* USER CODE END 1 */  
218
```

- HAL_GPIO_IRQHandler(B1_Pin); is called in EXTI15_10_IRQHandler
- Where is this function defined?
- IN the file stm32f4xx_hal_gpio.c

```
489 * @param GPIO_Pin Specifies the pins connected EXTI line  
490 * @retval None  
491 */  
492 void HAL_GPIO_EXTI_IRQHandler(uint16_t GPIO_Pin)  
493 {  
494     /* EXTI line interrupt detected */  
495     if(__HAL_GPIO_EXTI_GET_IT(GPIO_Pin) != RESET)  
496     {  
497         __HAL_GPIO_EXTI_CLEAR_IT(GPIO_Pin);  
498         HAL_GPIO_EXTI_Callback(GPIO_Pin);  
499     }  
500 }  
501  
502 /**  
503  * @brief EXTI line detection callbacks.  
504  * @param GPIO_Pin Specifies the pins connected EXTI line  
505  * @retval None  
506  */  
507 __weak void HAL_GPIO_EXTI_Callback(uint16_t GPIO_Pin)  
508 {  
509     /* Prevent unused argument(s) compilation warning */  
510     UNUSED(GPIO_Pin);  
511     /* NOTE: This function Should not be modified, when the callback is needed,  
512             the HAL_GPIO_EXTI_Callback could be implemented in the user file */  
513 }  
514  
515
```

- We have to implement the HAL_GPIO_EXTI_Callback function in main.c

Implement the callback function

```
MX HelloWorld.ioc  main.c  stm32f4xx_it.c  stm32f4xx_hal_gpio.c
93
94  /* Infinite loop */
95  /* USER CODE BEGIN WHILE */
96  while (1)
97  {
98      /* USER CODE END WHILE */
99
100     /* USER CODE BEGIN 3 */
101 }
102 /* USER CODE END 3 */
103 }
104
```

```
MX HelloWorld.ioc  main.c  stm32f4xx_it.c  stm32f4xx_hal_gpio.c
219
220 /* USER CODE BEGIN 4 */
221 void HAL_GPIO_EXTI_Callback(uint16_t GPIO_Pin){
222     if(GPIO_Pin == B1_Pin){
223         HAL_GPIO_TogglePin(LD2_GPIO_Port, LD2_Pin);
224     }
225 }
226 /* USER CODE END 4 */
227
```

- After making these changes, save, build project, and debug.

- Do nothing in the infinite loop
- The green led is to be toggled by the B1_Pin interrupt
- User implementation of the HAL_GPIO_EXTI_Callback function
- If the interrupt is trigger by B1_Pin, then toggle the led
- **Exercise:** Change the interrupt trigger to the Rising edge, and try again
- Which one (falling or rising) is better?

Timers

- Many embedded applications are time dependent
- Timers are the primary means by which the MCU controls the application
- It would be a great waste of the processing power if functions like `HAL_Delay()` are pervasively used to time processes
- Use hardware timers along with interrupts is the right way to implement embedded time-dependent applications
- Use case examples:
 - Measure the frequency of an incoming digital pulse train
 - Measure elapsed time on an output signal (called output compare for STM timers)
 - Generate precise PWM signals for servo and motor control
 - Generate single pulse with programmable length and delay
 - ADC (e.g., oscilloscope, audio signal) sampling at a given frequency

Timer setup

- A timer is essentially a counter
 - The clock source Frequency and the **Prescaler** controls how fast it counts
 - The timer's **Counter Period** determines how many counts before it's reset to 0, i.e., the timer's maximum counting value
 - A value of 0 turns off the timer - the timer will not run at all

Mode

☒ Activated

Channel1 Disable

☐ One P

Disable

Input Capture direct mode

Input Capture direct mode from Remap

Output Compare No Output

Output Compare CH1

PWM Generation No Output

PWM Generation CH1

Forced Output CH1

Configuration

Reset Configuration

☒ User Constants☒ NVIC Settings☒ Parameter Settings

Configure the below parameters :

Search (Ctrl+F)



Counter Settings

Prescaler (PSC - 16 .. 0

Counter Mode Up


Counter Period (Auto.. 65535

Internal Clock Divisio.. No Division

auto-reload preload Disable

Timer modes

- **Input Capture:** allows us to automatically store the timer's value when an event happens on a pin
- **Output Compare:** allows us to toggle a pin whenever the value in the timer reaches a certain amount
- **PWM Generation:** toggles a pin at different duty cycles based on a timer's counter value



$84 \text{ MHz} / 84 = 1 \text{ MHz} \rightarrow 1 \text{ tick} / \text{microsecond}$

Max time: $65535 * 1 \text{ microsecond} = 65.535 \text{ ms}$

The maximum time we can measure with this timer is about 65 milliseconds.

We will use this timer (TIM11) to measure how long something takes to process in the MCU

Save configuration, generate code, and go to main.c

Use hardware timer to time a block of code

```
22⓪ /* Private includes -----
23 /* USER CODE BEGIN Includes */
24 #include "stdio.h"
25 /* USER CODE END Includes */
26
```

```
68⓪ int main(void)
```

```
69 {
70     /* USER CODE BEGIN 1 */
71     char uart_buf[50];
72     int uart_buf_len;
73     uint16_t timer_val;
74     /* USER CODE END 1 */
75
```

```
92     /* Initialize all configured peripherals */
93     MX_GPIO_Init();
94     MX_USART2_UART_Init();
95     MX_TIM11_Init();
96     /* USER CODE BEGIN 2 */
97
98     uart_buf_len = sprintf(uart_buf, "Timer test\r\n");
99     HAL_UART_Transmit(&huart2, (uint8_t*)uart_buf, uart_buf_len, 100);
100     HAL_TIM_Base_Start(&htim11);
101
102     /* USER CODE END 2 */
103
```




- Use UART2 to output messages
- Use Putty at the STLink Virtual COM Port to receive
- Cannot use physical TX/RX pins on board unless solder bridge SB62 or SB63 is closed.

```
104     /* Infinite loop */
105     /* USER CODE BEGIN WHILE */
106     while (1)
107     {
108         // Get current time (microseconds)
109         timer_val = __HAL_TIM_GET_COUNTER(&htim11);
110         // any code we want to measure how long it takes to execute
111         // we will put a dummy delay here: wait for 50 ms
112         // Given the prescaler and period set up, TIM11 cannot measure anything longer than 65 ms
113         HAL_Delay(50);
114         // Get time elapsed
115         timer_val = __HAL_TIM_GET_COUNTER(&htim11) - timer_val;
116         // Show elapsed time
117         uart_buf_len = sprintf(uart_buf, "%u us\r\n", timer_val);
118         HAL_UART_Transmit(&huart2, (uint8_t *)uart_buf, uart_buf_len, 100);
119         // Wait again so we don't flood the Serial terminal
120         HAL_Delay(1000);
121         HAL_GPIO_TogglePin(LD2_GPIO_Port, LD2_Pin);
122
123         /* USER CODE END WHILE */
124
125         /* USER CODE BEGIN 3 */
126     }
127     /* USER CODE END 3 */
128 }
```

Use Serial port to receive uart2 messages



- Do nothing in the infinite loop
- The green led is to be toggled by the B1_Pin interrupt



TIM11 Mode and Configuration

Mode

☒ Activated

Channel1 Disable

☐ One Pulse Mode

Configuration

Reset Configuration

☒ Parameter Settings ☒ User Constants ☒ NVIC Settings

Configure the below parameters :

⏪ ⏩ ?

Counter Settings	
Prescaler (PSC - 16 bits value)	8400 - 1
Counter Mode	Up
Counter Period (AutoReload Register - 16 bits value)	65535
Internal Clock Division (CKD)	No Division
auto-reload preload	Disable

Non-blocking blinky using Timer


- $84 \text{ MHz} / 8400 = 10 \text{ kHz} \rightarrow 1 \text{ tick every } 0.0001 \text{ sec}$
- Can count up to $0.0001 * 65536 = 6.5536 \text{ sec}$

```



92  /* Initialize all configured peripherals */
93  MX_GPIO_Init();
94  MX_USART2_UART_Init();
95  MX_TIM11_Init();
96  /* USER CODE BEGIN 2 */
97
98  HAL_TIM_Base_Start(&htim11);
99  // Get current time
100 timer_val = __HAL_TIM_GET_COUNTER(&htim11);
101
102 /* USER CODE END 2 */
103
104 /* Infinite loop */
105 /* USER CODE BEGIN WHILE */
106 while (1)
107 {
108     // If enough time has passed (1 second, 10000 ticks, = 84 MHz/8400), toggle LED
109     // Below way to calculate elapsed time will work even if the timer rolls over to 0
110     // This creates non-blocking code to blink the LED every second
111     if(__HAL_TIM_GET_COUNTER(&htim11) - timer_val >= 10000){
112         HAL_GPIO_TogglePin(LD2_GPIO_Port, LD2_Pin);
113         timer_val = __HAL_TIM_GET_COUNTER(&htim11);
114     }
115
116     /* USER CODE END WHILE */
117
118     /* USER CODE BEGIN 3 */
119 }
120 /* USER CODE END 3 */

```

Timer triggered interrupt



Target event rate: 1 Hz
Time between target event: 1 sec
Clock speed: 84 MHz
Prescaler: 8400
Desired Period value:
 $1 \text{ sec} * (84 \text{ MHz} / 8400) = 10000$



Enable this, or interrupt won't trigger

Timer functions to use

68.2.3 Time Base functions

This section provides functions allowing to:

- Initialize and configure the TIM base.
- De-initialize the TIM base.
- Start the Time Base.
- Stop the Time Base.
- Start the Time Base and enable interrupt.
- Stop the Time Base and disable interrupt.
- Start the Time Base and enable DMA transfer.
- Stop the Time Base and disable DMA transfer.

This section contains the following APIs:

- `HAL_TIM_Base_Init()`
- `HAL_TIM_Base_DeInit()`
- `HAL_TIM_Base_MspInit()`
- `HAL_TIM_Base_MspDeInit()`
- `HAL_TIM_Base_Start()`
- `HAL_TIM_Base_Stop()`
- `HAL_TIM_Base_Start_IT()`
- `HAL_TIM_Base_Stop_IT()`
- `HAL_TIM_Base_Start_DMA()`
- `HAL_TIM_Base_Stop_DMA()`

- TIM Period elapsed callback
- TIM Output Compare callback
- TIM Input capture callback
- TIM Trigger callback
- TIM Error callback

This section contains the following APIs:

- `HAL_TIM_PeriodElapsedCallback()`
- `HAL_TIM_PeriodElapsedHalfCpltCallback()`
- `HAL_TIM_OC_DelayElapsedCallback()`
- `HAL_TIM_IC_CaptureCallback()`
- `HAL_TIM_IC_CaptureHalfCpltCallback()`
- `HAL_TIM_PWM_PulseFinishedCallback()`
- `HAL_TIM_PWM_PulseFinishedHalfCpltCallback()`
- `HAL_TIM_TriggerCallback()`
- `HAL_TIM_TriggerHalfCpltCallback()`
- `HAL_TIM_ErrorCallback()`

This function gets called whenever the timer resets

Use this function to start timer if we are using interrupts

https://www.st.com/resource/en/user_manual/dm00105879-description-of-stm32f4-hal-and-ll-drivers-stmicroelectronics.pdf

Code to blink LED using Timer triggered Interrupt

```
92  /* Initialize all configured peripherals */
93  MX_GPIO_Init();
94  MX_USART2_UART_Init();
95  MX_TIM11_Init();
96  /* USER CODE BEGIN 2 */
97  // Start timer in interrupt mode
98  HAL_TIM_Base_Start_IT(&htim11);
99
100 /* USER CODE END 2 */
101
102 /* Infinite loop */
103 /* USER CODE BEGIN WHILE */
104 while (1)
105 {
106     /* USER CODE END WHILE */
107
108     /* USER CODE BEGIN 3 */
109 }
110 /* USER CODE END 3 */
111 }
```

Implement the Callback function in main.c

```
259 /* USER CODE BEGIN 4 */
260 void HAL_TIM_PeriodElapsedCallback(TIM_HandleTypeDef *htim){
261     // Check which version of the timer triggered this callback and toggle LED
262     if (htim == &htim11){
263         HAL_GPIO_TogglePin(LD2_GPIO_Port, LD2_Pin);
264     }
265 }
266 /* USER CODE END 4 */
```


Be careful with the function name here. If it's misspelled, no error will occur, but the LED will not light

Use UART Rx to receive data

- There are several ways.
- **Polling:** call `HAL_UART_Receive()` in `while(1)` loop
 - Other executions are blocked until the data is received or the timeout happens.
- **Interrupt:** call `HAL_UART_Receive_IT()` before `while(1)` loop, and implement user callback function `HAL_UART_RxCpltCallback()` to handle event (e.g., process the received data)
 - USART2 global interrupt must be enabled in NVIC, [see next slide](#)
 - Inside the callback function, need to make a call to `HAL_UART_Receive_IT()` to restart, i.e., continue receiving data in interrupt mode
 - At beginning of the callback function body, use this to respond to the right UART:
 - `if(huart->Instance == USART2){ /* Do everything in this block */ } else { /* Do nothing */ }`
- **DMA:** call `HAL_UART_Receive_DMA()` before `while(1)` loop, and implement callback functions
 - `HAL_UART_RxCpltCallback()`
 - `HAL_UART_RxHalfCpltCallback()` // perform some tasks when half the Rx buffer is filled



Enable USART2 global interrupt



The screenshot shows the STM32CubeMX interface for configuring the NVIC. The left sidebar lists various system components, with 'NVIC' selected under the 'System Core' category. The main window displays the 'NVIC Mode and Configuration' settings. The 'Configuration' tab is active, showing the 'NVIC Interrupt Table' with columns for 'Enabled', 'Preemption Priority', and 'Sub Priority'. The 'USART2 global interrupt' is highlighted, and its 'Enabled' checkbox is checked. The 'Preemption Priority' and 'Sub Priority' are both set to 0.

NVIC Interrupt Table	Enabled	Preemption Priority	Sub Priority
Non maskable interrupt	☒	0	0
Hard fault interrupt	☒	0	0
Memory management fault	☒	0	0
Pre-fetch fault, memory access fault	☒	0	0
Undefined instruction or illegal state	☒	0	0
System service call via SWI instruction	☒	0	0
Debug monitor	☒	0	0
Pendable request for system service	☒	0	0
Time base: System tick timer	☒	0	0
PVD interrupt through EXTI line 16	☐	0	0
Flash global interrupt	☐	0	0
RCC global interrupt	☐	0	0
TIM1 trigger and commutation interrupts and TIM11 global interrupt	☒	0	0
USART2 global interrupt	☒	0	0
EXTI line[15:10] interrupts	☒	0	0
FPU global interrupt	☐	0	0

Useful UART functions

```
722 /* IO operation functions *****/
723 HAL_StatusTypeDef HAL_UART_Transmit(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size, uint32_t Timeout);
724 HAL_StatusTypeDef HAL_UART_Receive(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size, uint32_t Timeout);
725 HAL_StatusTypeDef HAL_UART_Transmit_IT(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size);
726 HAL_StatusTypeDef HAL_UART_Receive_IT(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size);
727 HAL_StatusTypeDef HAL_UART_Transmit_DMA(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size);
728 HAL_StatusTypeDef HAL_UART_Receive_DMA(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size);
729 HAL_StatusTypeDef HAL_UART_DMAPause(UART_HandleTypeDef *huart);
730 HAL_StatusTypeDef HAL_UART_DMAResume(UART_HandleTypeDef *huart);
731 HAL_StatusTypeDef HAL_UART_DMAStop(UART_HandleTypeDef *huart);
732
733 HAL_StatusTypeDef HAL_UARTEx_ReceiveToIdle(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size, uint16_t *RxLen,
734                                           uint32_t Timeout);
735 HAL_StatusTypeDef HAL_UARTEx_ReceiveToIdle_IT(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size);
736 HAL_StatusTypeDef HAL_UARTEx_ReceiveToIdle_DMA(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size);
737
738 /* Transfer Abort functions */
739 HAL_StatusTypeDef HAL_UART_Abort(UART_HandleTypeDef *huart);
740 HAL_StatusTypeDef HAL_UART_AbortTransmit(UART_HandleTypeDef *huart);
741 HAL_StatusTypeDef HAL_UART_AbortReceive(UART_HandleTypeDef *huart);
742 HAL_StatusTypeDef HAL_UART_Abort_IT(UART_HandleTypeDef *huart);
743 HAL_StatusTypeDef HAL_UART_AbortTransmit_IT(UART_HandleTypeDef *huart);
744 HAL_StatusTypeDef HAL_UART_AbortReceive_IT(UART_HandleTypeDef *huart);
745
746 void HAL_UART_IRQHandler(UART_HandleTypeDef *huart);
747 void HAL_UART_TxCpltCallback(UART_HandleTypeDef *huart);
748 void HAL_UART_TxHalfCpltCallback(UART_HandleTypeDef *huart);
749 void HAL_UART_RxCpltCallback(UART_HandleTypeDef *huart);
750 void HAL_UART_RxHalfCpltCallback(UART_HandleTypeDef *huart);
751 void HAL_UART_ErrorCallback(UART_HandleTypeDef *huart);
752 void HAL_UART_AbortCpltCallback(UART_HandleTypeDef *huart);
753 void HAL_UART_AbortTransmitCpltCallback(UART_HandleTypeDef *huart);
754 void HAL_UART_AbortReceiveCpltCallback(UART_HandleTypeDef *huart);
755
756 void HAL_UARTEx_RxEventCallback(UART_HandleTypeDef *huart, uint16_t Size);
757
```

Use DMA to transfer data to UART Tx (Polling)

DMA Mode and Configuration			
Configuration			
☒ DMA1	☒ DMA2	☒ MemToMem	
DMA Request	Stream	Direction	Priority
USART2_TX	DMA1 Stream 6	Memory To Peripheral	Low

NVIC Interrupt Table	Enabled	Preemption Priority	Sub P
Non maskable interrupt	☒	0	0
Hard fault interrupt	☒	0	0
Memory management fault	☒	0	0
Pre-fetch fault, memory access fault	☒	0	0
Undefined instruction or illegal state	☒	0	0
System service call via SWI instruction	☒	0	0
Debug monitor	☒	0	0
Pendable request for system service	☒	0	0
Time base: System tick timer	☒	0	0
PVD interrupt through EXTI line 16	☐	0	0
Flash global interrupt	☐	0	0
RCC global interrupt	☐	0	0
DMA1 stream6 global interrupt	☒	0	0
TIM2 global interrupt	☐	0	0
USART2 global interrupt	☐	0	0
EXTI line[15:10] interrupts	☐	0	0
FPU global interrupt	☐	0	0

- Before the while(1) loop, add
 - `HAL_UART_MspInit(&huart2);`
- In the while(1) loop:

```
huart2.Instance->CR3 |= USART_CR3_DMAT;  
  
HAL_DMA_Start(&hdma_usart2_tx, (uint32_t)msg,  
(uint32_t)&huart2.Instance->DR,  
(uint32_t)strlen(msg));  
  
HAL_DMA_PollForTransfer(&hdma_usart2_tx,  
HAL_DMA_FULL_TRANSFER, HAL_MAX_DELAY);  
  
huart2.Instance->CR3 &= ~USART_CR3_DMAT;  
  
HAL_GPIO_TogglePin(GPIOA, GPIO_PIN_5);  
  
HAL_Delay(1000);
```

Use DMA to transfer data to UART Tx (Interrupt)

```
/* USER CODE BEGIN 2 */
HAL_UART_MspInit(&huart2);
HAL_DMA_RegisterCallback(&hdma_usart2_tx, HAL_DMA_XFER_CPLT_CB_ID, &DMATransferComplete);
```

Register a user callback function, let us name it DMATransferComplete

In the while(1) loop:

```
// USART Control register 3 bitwise or with DMA enable Transmitter
// Enable the DMA transmit bit which tells the usart peripheral that
// we plan to send out data via DMA
huart2.Instance->CR3 |= USART_CR3_DMAT;
// Tell the DMA instance hdma_usart2_tx to start the Interrupt mode
// to use the msg in memory as the source, the destination address is
// the transmit data register DR, the message length is strlen(msg)
HAL_DMA_Start_IT(&hdma_usart2_tx, (uint32_t)msg, (uint32_t)&huart2.Instance->DR, (uint32_t)strlen(msg));
HAL_Delay(1000);
```

```
void DMATransferComplete(DMA_HandleTypeDef *hdma){
    // Disable UART DMA mode, so UART can be used for other purposes
    huart2.Instance->CR3 &= ~USART_CR3_DMAT;
    // Toggle LED
    HAL_GPIO_TogglePin(GPIOA, GPIO_PIN_5);
}
```

Definition of the callback function

Compared to the Polling method, the interrupt method does not block the process, especially when the message (msg) size is large.

ADC (Polling)

```
106  /* Infinite loop */
107  /* USER CODE BEGIN WHILE */
108  while (1)
109  {
110      // set LED pin high
111      HAL_GPIO_WritePin(GPIOA, GPIO_PIN_5, GPIO_PIN_SET);
112      // Get ADC value
113      HAL_ADC_Start(&hadc1);
114      HAL_ADC_PollForConversion(&hadc1, HAL_MAX_DELAY);
115      adc_val = HAL_ADC_GetValue(&hadc1);
116      // set LED pin low
117      HAL_GPIO_WritePin(GPIOA, GPIO_PIN_5, GPIO_PIN_SET);
118      // Transmit value via uart2
119      buflen = sprintf(buf, "%hu\r\n", adc_val);
120      HAL_UART_Transmit(&huart2, (uint8_t*)buf, buflen, HAL_MAX_DELAY);
121      // Add a 1 ms delay
122      HAL_Delay(1);
123      /* USER CODE END WHILE */
124
125      /* USER CODE BEGIN 3 */
126  }
127  /* USER CODE END 3 */
128 }
129
```

ADC1 Mode and Configuration

Mode

- ☒ IN0
- ☐ IN1
- ☒ IN2
- ☒ IN3
- ☐ IN4
- ☒ IN5
- ☐ IN6
- ☐ IN7

Configuration

Reset Configuration

☒ NVIC Settings ☒ DMA Settings ☒ GPIO Settings ☒ Parameter Settings ☒ User Constants

Search (Ctrl+F)

ADCs_Common_Settings

Mode: Independent mode

ADC_Settings

Clock Prescaler: PCLK2 divided by 4

Resolution: 12 bits (15 ADC Clock cycles)

Data Alignment: Right alignment

Scan Conversion Mode: Disabled

Continuous Conversion Mode: Disabled

Discontinuous Conversion Mode: Disabled

DMA Continuous Requests: Disabled

End Of Conversion Selection: EOC flag at the end of single channel conversi.

ADC_Regular_ConversionMode


Number Of Conversion: 1

Scan Conversion Mode

Scan Conversion Mode

Parameter Description:

ADC (DMA)



```
/* Private user code -----
/* USER CODE BEGIN 0 */
uint16_t buf[4096];
/* USER CODE END 0 */
```


```
/* USER CODE BEGIN 2 */
HAL_ADC_Start_DMA(&hadc1, (uint32_t*)buf, 4096);
/* USER CODE END 2 */
```

Empty while (1) loop will work

```
void HAL_ADC_ConvHalfCpltCallback(ADC_HandleTypeDef* hadc){
    HAL_GPIO_WritePin(GPIOA, GPIO_PIN_5, GPIO_PIN_SET);
}
```

```
void HAL_ADC_ConvCpltCallback(ADC_HandleTypeDef* hadc){
    HAL_GPIO_WritePin(GPIOA, GPIO_PIN_5, GPIO_PIN_RESET);
}
```

```
/* USER CODE END 4 */
```




- Analog samples continuously enter memory (buf) without CPU intervention
- Each time half and full buf is filled, a respective event is triggered. Write callback to handle them, e.g., process / copy the data

- Sampling frequency is determined by clock and prescaler
- Useful for audio sampling

Pulse width modulation (PWM)


- A digital signal generated by the MCU for a variety of purposes, e.g.,
 - Set the position of a standard servo motor
 - Control the rotational speed of a continuous rotation motor
 - Control the luminescence of a light emitter
 - Control the rotational speed of a standard electric motor with external driver circuitry
 - Control a photovoltaic solar battery charger's charging rate
 - Generate a waveform such as sine, triangle and square
 - Generate acoustic sound waveform

PWM configuration




- Frequency
 - 50 Hz (or equivalently 20 ms period) is common for servo control
- Duty cycle
 - The percentage of the amount of time the signal is in the high state during a period
- PWM signals are generated by a Timer

Generate PWM to toggle the LED



- Configure TIM2 for PWM
 - TIM2 Channel 1 (CH1), assign to PA5
 - Clock Source: Internal Clock (84 MHz)
 - Channel 1: PWM Generation CH1
 - Prescaler: 10000
 - So, counter frequency = $84 \text{ MHz} / 10000 = 8400 \text{ Hz}$
 - Counter Period: 16800
 - So, timer resets every $16800 / 8400 \text{ Hz} = 2 \text{ sec}$
 - The PWM signal frequency is therefore 2 sec
 - Pulse: 8400
 - Duty cycle = $\text{Pulse} / \text{Period} = 8400 / 16800 = 50\%$
 - `HAL_TIM_PWM_Start(&htim2, TIM_CHANNEL_1);` in `main.c` before `while(1)` loop
- Result: the green led (PA5) toggles at 1Hz



Use PWM to dim the LED

The screenshot shows the STM32CubeMX configuration interface for TIM2. The 'Mode' section has the following settings:

- Slave Mode: Disable
- Trigger Source: Disable
- Clock Source: Internal Clock
- Channel1: PWM Generation CH1
- Channel2: Disable
- Channel3: Disable
- Channel4: Disable
- Combined Channels: Disable

The 'Configuration' section has the following settings:

- Reset Configuration: (button)
- NVIC Settings: (checked)
- DMA Settings: (checked)
- GPIO Settings: (checked)
- Parameter Settings: (checked and selected)
- User Constants: (checked)

Configure the below parameters :

Search (Ctrl+F)

Counter Settings

- Prescaler (PSC - 16 bits value): 10000 - 1
- Counter Mode: Up
- Counter Period (AutoReload Register - 32 .. 168 - 1):
- Internal Clock Division (CKD): No Division
- auto-reload preload: Disable

Trigger Output (TRGO) Parameters

- Master/Slave Mode (MSM bit): Disable (Trigger input effect not delayed)
- Trigger Event Selection: Reset (UG bit from TIMx_EGR)

PWM Generation Channel 1

- Mode: PWM mode 1
- Pulse (32 bits value): 21 - 1
- Output compare preload: Enable
- Fast Mode: Disable
- CH Polarity: High

- Based on the previous example, modify
 - Prescaler: 168
 - So, the counter frequency is 50 Hz
 - Pulse: 21
 - So, the duty cycle is 12.5%
- Result
 - The green led is on but looks dim
- Exercise
 1. Try some other Prescaler and Pulse values
 2. Assign TIM2_CH1 to PA0, and use an oscilloscope to visualize the signal


Use PWM to control a servo motor

- A typical servo motor expects to be updated every 20 ms with a pulse between 1 ms and 2 ms, or in other words, between a 5 and 10% duty cycle on a 50 Hz waveform. With a 1.5 ms pulse, the servo motor will be at the natural 90 degree position. With a 1 ms pulse, the servo will be at the 0 degree position, and with a 2 ms pulse, the servo will be at 180 degrees.



<https://learn.sparkfun.com/tutorials/pulse-width-modulation/all>

Update the duty cycle in the program



The screenshot shows the STM32CubeMX configuration interface for TIM2. The 'Mode' tab is active, displaying settings for Slave Mode (Disable), Trigger Source (Disable), Clock Source (Internal Clock), and Channels 1-4 (all Disable). The 'Configuration' tab is also visible, showing a search bar and a list of parameters including Counter Settings, Trigger Output (TRGO) Parameters, and PWM Generation Channel 1. The PWM Generation Channel 1 settings are expanded, showing Mode (PWM mode 1), Pulse (32 bits value) set to 21, Output compare preload (Enable), Fast Mode (Disable), and CH Polarity (High).

- The Pulse value is stored in the register
 - TIM2->CCR1
 - Timer 2 Channel 1's Capture Compare Register
 - This register value can be updated in user code

```
71 int main(void)
72 {
73     /* USER CODE BEGIN 1 */
74     int pulse = 20 - 1;
75     uint8_t dir = 1;
76     /* USER CODE END 1 */
77 }
```


Experiment: Vary the CCR1 value in the while(1) loop

Result: the green led will gradually light up and dim down.

```
101 HAL_TIM_PWM_Start(&htim2, TIM_CHANNEL_1);
102 /* USER CODE END 2 */
103
104 /* Infinite loop */
105 /* USER CODE BEGIN WHILE */
106 while (1)
107 {
108     if(pulse==80) dir = 0;
109     if(pulse==1) dir = 1;
110     if(dir == 1){
111         pulse++;
112     } else {
113         pulse--;
114     }
115     TIM2->CCR1 = pulse;
116     HAL_Delay(20);
117 }
```

Exercise: This execution is blocking. Change it to non-blocking mode by using a different timer (e.g., TIM11) to trigger the adjustment of TIM2->CCR1, every 20 ms.

DAC



Digital To Analog Converter

https://www.st.com/resource/en/application_note/cd00259245-audio-and-waveform-generation-using-the-dac-in-stm32-products-stmicroelectronics.pdf

Figure 3. DAC interaction without DMA





Figure 4. DAC interaction with DMA



DAC with DMA

TIM2 Mode and Configuration

Mode

Slave Mode

Trigger Source

Clock Source

Channel1

Channel2

Channel3

Channel4

Combined Channels

Configuration

☒ Parameter Settings ☒ User Constants ☒ NVIC Settings ☒ DMA Settings

Configure the below parameters :

Search (Ctrl+F)

Counter Settings

Prescaler (PSC - 16 bits value) 1000 - 1

Counter Mode Up

Counter Period (AutoReload Register) 1680 - 1

Internal Clock Division (CKD) No Division

auto-reload preload Disable

Trigger Output (TRGO) Parameters

Master/Slave Mode (MSM bit) Disable (Trigger input effect not delayed)

Trigger Event Selection Update Event

DAC Mode and Configuration

Mode

☒ OUT1 Configuration

☒ OUT2 Configuration

☐ External Trigger

Configuration

☒ NVIC Settings ☒ DMA Settings ☒ GPIO Settings

☒ Parameter Settings ☒ User Constants

Configure the below parameters :

Search (Ctrl+F)

DAC Out1 Settings

Output Buffer Enable

Trigger None

None

Timer 2 Trigger Out event

Timer 4 Trigger Out event

Timer 5 Trigger Out event

Timer 6 Trigger Out event

Timer 7 Trigger Out event

Timer 8 Trigger Out event

Software trigger

- Output a sine wave through DAC Channel 1, assigned to Pin PA4
- The DAC is triggered by Timer 2
- TIM2 Trigger Event Selection is set to Update Event
- TIM2's clock source is 84 MHz
- Prescaler: 1000
- Period: 1680
- So, $84 \text{ MHz} / 1000 / 1680 = 50 \text{ Hz}$
- This means there are 50 DAC conversions per second
- The sine wave is represented by NSAMP = 100 samples, meaning 100 DAC conversions per sine cycle
- So, the sine wave frequency is $50 / 100 = 0.5 \text{ Hz}$
- The analog signal output is used for driving a LED
- See video clip

DAC with DMA

```
/* Private define -----  
/* USER CODE BEGIN PD */  
#define NSAMP 100  
#define PI 3.1415926  
/* USER CODE END PD */  
  
uint16_t sine_data[NSAMP];  
for(int i=0; i<NSAMP; i++){  
    sine_data[i] = (0xFFF+1)/2*(sin(i*2*PI/NSAMP)+1);  
}  
  
/* Initialize all configured peripherals */  
MX_GPIO_Init();  
MX_USART2_UART_Init();  
MX_TIM2_Init();  
MX_DMA_Init();  
MX_DAC_Init();  
/* USER CODE BEGIN 2 */  
  
HAL_TIM_Base_Start(&htim2);  
HAL_DAC_Start_DMA(&hdac, DAC_CHANNEL_1, (uint32_t *)sine_data, NSAMP, DAC_ALIGN_12B_R)
```

The while(1) loop is empty

- Video clip

The sampling step is $2\pi / n_s$ (number of samples).

The value of $\sin(x)$ varies between -1 and 1, we have to shift it up to have a positive sine wave with samples varying between 0 and 0xFFF (corresponding to the 0 to 3.3 V voltage range, where V_{REF} is set to 3.3 V).

$$y_{SineDigital}(x) = \left(\sin\left(x \cdot \frac{2\pi}{n_s}\right) + 1 \right) \left(\frac{(0xFFF + 1)}{2} \right)$$

Digital inputs are converted to output voltages on a linear conversion between 0 and V_{REF+} .

The analog output voltages on each DAC channel pin are determined by the equation

$$V_{Output} = V_{REF} \frac{DOR}{DAC_MaxDigitalValue + 1}$$

For right-aligned 12-bit resolution: $DAC_MaxDigitalValue = 0xFFF$

For right-aligned 8-bit resolution: $DAC_MaxDigitalValue = 0xFF$

So the analog sine waveform $y_{SineAnalog}$ can be determined by the following equation

$$y_{SineAnalog}(x) = 3.3V_{olt} \frac{y_{SineDigital}(x)}{0xFFF + 1}$$

To set the frequency of the sine wave signal, the user has to set the frequency ($f_{TimerTRGO}$) of the timer trigger output.

The frequency of the produced sine wave is

$$f_{Sinewave} = \frac{f_{TimerTRGO}}{n_s}$$

Final notes

- In all experiments, we used the default Clock Configuration (HCLK = 84 MHz)
 - For control projects, the lowest frequency that is high enough to meet the application's response requirement should be used. Lower CPU speed means lower power consumption.
 - For digital processing, the clock frequency may be configured so that some timer (e.g., the trigger timer for DAC) can produce the desired signal frequency (e.g., 44.1 kHz for audio).

References

- STM32CubeIDE Advanced Debug Features: Part 3
 - https://youtu.be/Eg_GLvLHM1o
- Programming with STM32 Getting Started with the Nucleo Board and C/C++, by Donald Norris, McGraw Hill Education, 2018
 - <https://www.amazon.com/Programming-STM32-Getting-Started-Nucleo/dp/1260031314>
- Getting Started with STM32 and Nucleo Part 6: Timers and Timer Interrupts | Digi-Key Electronics
 - <https://youtu.be/VfbW6nfG4kw>
- Receive data using UART in STM32 || Poll || Interrupt || DMA
 - <https://youtu.be/l5msGz2tZP0>